

Alltek Nuance Toscane

Decorative ready-mix plaster | Manual application | Indoor application

DESCRIPTION

White decorative plaster made from very fine mineral fillers and organic binder. It allows for smooth, tinted, and/or 'marbled' effects.

USF

- · Interior decorative plaster for walls and ceilings on all common smooth and prepared substrates.
- · Individual or collective premises.

TECHNICAL SPECIFICATIONS

TYPICAL SPREADABILITY:

6 kg for approximately 10 m² per coat depending on the desired

DENSITY:

1,7 +/- 0,1 kg/l

SOLID CONTENT:

- . Solid content by weight: 74%
- . Solid content by volume: 55%

APPLICATION CONDITIONS:

- +8°C to +35°C
- . Maximum humidity 70% RH

PACKAGING AND STORAGE

- 6kg plastic bucket.
- Shelf life of 2 years in unopened original packaging, protected from frost and excessive heat.

ENVIRONMENTAL INFORMATION

- VOC content: < 1 g/L.
- Indoor Air Emission Class



CHARACTERISTICS

- Fire classification: A2-s1, d0 according to European standard EN 13501-1.
- . Classification: family III class 2 according to AFNOR NF T 36-005, compliant with AFNOR standard NF T 30-608.

HEALTH AND SAFETY

The safety data sheet is available on the website: https://icp-alltek.com/en-gb/ documentation/

PH:

8 ± 1

CLEANING TOOLS:

With water

RECOMMENDED THICKNESSES:

- . Minimum thickness: 0.3 mm for the first coat
- . Maximum thickness: 0.5 mm for the first coat

DRYING:

• Approximately 16 hours depending on application thickness, temperature, ventilation, humidity, and substrate type. Sanding and covering: after complete drying.

METHOD OF APPLICATION

SUBSTRATES:

- · Cardboard plasterboards.
- . All smooth and revised current supports, if necessary, with Alltek LF50 or Alltek LM150

PREPARATION OF SUBSTRATE:

• The supports, preparatory work, and conditions of application will be in accordance with the DTU and current standards.

APPLICATION TIPS:

- After removing the protective film from the product, mix with an electric stirrer.
- First layer: apply a thin coat with a spatula or trowel (with rounded corners) irregularly to create a relief (dips and thickening) by tilting the spatula as much as possible (almost parallel to the application surface).
- After drying (about 6 hours) apply a second coat.
- The spatula should be held as perpendicularly as possible to the surface being applied, as it is meant to fill the hollows of the reliefs, with strong pressure to achieve the maximum shine (tamping of the coating).
- · After drying, cover the Toscane shade with the protective wax Stucco Wax, which will give it a silky and very shiny appearance after burnishing.

RECOMMENDATIONS:

- . Ventilate the room during application and drying.
- Use clean and properly maintained PPE: gloves and eye protection designed against liquid splashes, mask during sanding operations.
- To clean tools, scrape off excess and immerse in a minimum amount of water.
- . Do not dispose of residues in the sewer. Dispose of contents/container at a hazardous or special waste collection center.
- Conserver à l'abri du gel et de la chaleur.
- . Tightly reseal the container after use.
- Ensure adequate ventilation to remove excess humidity and speed up drying.

